

ENGINE SERIAL NUMBER PLATE

The engine serial number plate is located under the air cleaner.

Refer to the engine model designation on your engine's serial number plate to identify repair information covered in the Component Technical Manual.



M98,INTR,2 -19-07OCT85

BASIC ENGINE SPECIFICATIONS

ENGINE	B43E	B43G	P218G	B48G and P220G	T260
CYLINDER	2	2	2	2	2
CYCLE	4	4	4	4	4
BORE	82.55 mm (3.25 in.)	82.55 mm (3.25 in.)	82.55 mm (3.25 in.)	82.55 mm (3.25 in.)	90.42 mm (3.56 in.)
STROKE	66.55 mm (2.62 in.)	66.55 mm (2.62 in.)	73 mm 2.875 in.)	73 mm (2.87 in.)	76.20 mm (3.00 in.)
DISPLACEMENT	710 cm ³ (43.3 cu in.)	710 cm ³ (43 cu in.)	782 cm ³ 47.7 cu in.)	782 cm ³ (48 cu in.)	983 cm ³ (60 cu in.)
*HORSEPOWER	12kW (16 hp)	13.5 kW (18 HP)	13.4 kW (18 hp)	15 kW (20 hp)	18 kW (24 hp)

**Horsepower rating is established by engine manufacturer in accordance with Standard International Combustion Institute procedure. It is corrected to (60 °F) and 29.92 hg barometer. Laboratory test engines are equipped with air cleaner and muffler.*

M98,INTR,3 -19-10FEB87